



Kodak FunSaver flash disposable camera, colour film and flash, 27 photos, ISO 400



Modelis: 8617763

Gamintojas: KODAK

EAN: 041778617762

Prekės kodas: 381169

24.99€

Film type: 35 mm | Depth: 38 mm | Number of shots: 27 | Weight: 128.000006 g | Camera shutter type: Electronic | Flash range (wide): 3 | Built-in flash: Yes | Product colour: Black | Product colour: Yellow | Camera type: Disposable camera | Product colour: Red | Flash modes: Auto | Film speed setting (ISO): 400 | Width: 63 mm | Height: 120 mm | Auto focus: Yes

Pateikta prekės informacija yra orientacinio pobūdžio. Techninės savybės, nuotraukos, aprašymai ir kaina gali keistis be išankstinio perspėjimo. Gamintojas ir pardavėjas neatsako už galimus duomenų neatitikimus ar tipografines klaidas. Prieš įsigyjant rekomenduojame pasitikrinti aktualią informaciją.

www.shopro.lt | info@shopro.lt | +370 693 39903