



DJI Osmo Action 3 Multifunctional Battery Case

Modelis: CP.OS.00000230.01

Gamintojas: DJI

EAN: 6941565945020

Prekės kodas: 585188

85.99€

Osmo Action 3 multifunctional battery case

The case stores 3 rechargeable batteries and 2 microSD cards. It quickly charges the 3 batteries and can be used together as a powerbank to charge other devices such as a smartphone.

Specification:

Manufacturer	DJI
Name	Osmo Action 3 multifunctional battery case
Dimensions	116.2 × 59.2 × 22.9 mm

Pateikta prekės informacija yra orientacinio pobūdžio. Techninės savybės, nuotraukos, aprašymai ir kaina gali keistis be išankstinio perspėjimo. Gamintojas ir pardavėjas neatsako už galimus duomenų neatitikimus ar tipografines klaidas. Prieš įsigyjant rekomenduojame pasitikrinti aktualią informaciją.

www.shopro.lt | info@shopro.lt | +370 693 39903

Weight

110 g

Last delivery: 20.08.2026, Compatibility: DJI Osmo, Net weight: 100, Box length: 12,00, Box width: 6,50, Box height: 2,50, Gross weight: 120, Seria Action: DJI Osmo Action 3, GPSR Link: https://psr-assets.innpro.pl/photo_and_accessories/sg_photo_and_accessories_photo_accessories.pdf, Rodzaj produktu: Kable i ładowarki, Information about data generation: <https://dataact.innpro.pl/dji/6941565945020>