

18V ONE+ OCS1830 RYOBI chainsaw

Gamintojas: **RYOBI** · Modelis: **5133002829** · EAN: **4892210147820** · Prekės kodas: **904935**



151,90 €

Kaina su PVM

Be PVM: **125,54 €**

Sandėlyje



Prekė internetu

Nuskenaukite kodą arba apsilankykite www.shopro.lt

Aprašymas

Vibration level: 6.6 m/s² | Product colour: Black | Input voltage: 18 V | Weight: 3.2 kg | Chain pitch: 9.53 / 0.375 mm (0.375 / 0.375") | Warnings: Keep the unit away from sources of heat and fire. | Product colour: Green | Power source: Battery | Chain speed: 10 m/s | Warnings: Do not dispose of used batteries in the normal waste stream hand them in at a designated collection point. | Warnings: Use appropriate protective equipment such as gloves and safety glasses. | Engine type: Brushless motor | Charger: No | Chain bar length: 30 cm | Sound power level : 94.1 dB(A) | Battery included: No

Techninė specifikacija

Matmenys ir svoris

Matmenys (I × P × A) 24,00cm × 22,00cm × 59,00cm

Svoris 4,55kg