

Sony FAWRC1M.CE7

Gamintojas: **SONY** · Modelis: **FA-WRAC1M** · EAN: **4548736038981** · Prekės kodas: **906091**

442,90 €

Kaina su PVM

Be PVM: **366,03 €**

Sandėlyje



Prekė internetu

Nuskenaukite kodą arba apsilankykite www.shopro.lt

Aprašymas

Wireless Radio Commander

Radio remote flash control for creative lighting ideas

Trigger multiple flash units or multiple camera shutters

Connect the FA-WRC1M to up to 15 wireless receivers (FA-WRR1) for radio wireless flash control of even large lighting setups. Use your existing α flash units such as HVL-F60M, F43M or F32M over a wide range of up to 30m (98.4ft). With flash unit grouping you can expand your lighting in inventive ways. With the multi-terminal connection on radio receivers, you can also trigger multiple simultaneous camera shutters, for boundless creativity.

Creative freedom with minimum equipment

Control multiple flashes for unique looks

Spend less time setting up, and more time capturing great images. After attaching FA-WRC1M to your compatible camera¹, attach up to 15 radio receivers to flashes, then quickly and easily pair FA-WRC1M to each receiver. Pair up to 15 receivers within up to 5 groups² for accurate radio transmissions. Easily control multiple flash units for more creative lighting options.

Reliable and precise control in any setting

Radio signals deliver more detailed, more precise shooting information over a wider shooting area (about 30m / 98.4ft). Signals reach wireless receivers, even in bright light or around obstacles, even when installed behind the camera. Achieve more consistent results without pairing errors.

Convenient remote flash setting confirmation

Remotely adjust flash settings on FA-WRC1M. Easily control complex lighting setups alone or with a small crew. Confirm exposure compensation, flash intensity, etc., or independently adjust receiver settings. Adjust flash strength or use Zoom to change flash angles.

Remotely control multiple shutters

Use remote release function to control multiple cameras

Simultaneously release shutters on multiple cameras using remote shooting function. Use separately sold Multi Terminal cables to connect wireless radio receivers to cameras to accurately and reliably shoot one subject from multiple angles at the same time.

Essential wireless radio system components

Combine these tools for complete wireless radio control

To enjoy wireless flash triggering, you must pair the FA-WRC1M wireless radio commander with at least one wireless radio receiver (FA-WRR1) for a complete wireless radio control system. Add Multi Terminal cables (VMC-MM1) between cameras and receivers to further expand the possibilities of your wireless radio control system with remote and multi-angle shooting.

Techninė specifikacija

Technical details	
Camera brands compatibility	Sony
Product colour	Black
Maximum range	30 m
Built-in display	Yes
Control type	Buttons
Matmenys ir svoris	
Svoris	1,00kg

Dokumentai ir vaizdo įrašai

› [Vaizdo įrašas](#) youtube.com/watch?v=dQC-vfYk5rM

Gamintojo ir saugos informacija

GAMINTOJAS

Sony

PLATINTOJAS

MB KOMPIUTERIŲ GURU

V. Nagevičiaus g. 3, LT-08237 Vilnius

info@shopro.lt